



RV-8 BAGGAGE DOOR

→ RIGHT/FOREWARD ←

BEND FOR TIGHT FIT
AGAINST FUSELAGE AT
BOTTOM.



RV-8 BAGGAGE

→ LEFT/AFT ←

BEND FOR TIGHT FIT
AGAINST FUSELAGE AT
BOTTOM