

Locate Fuel Fitting on Firewall

Locate the fuel fitting on the right hand side of the firewall in an open area below the stiffener shelf. Take note in locating the fitting that there is sufficient clearance on the



cabin side of the firewall so that the fuel line running to the fitting does not interfere with the rudder pedals. See photos for general position. Rivet the fitting in place with 3/16 rivets provided.





This photo shows the firewall fitting installed and angling toward the left side of the fuselage where the fuel line will come from.



Measure the fuel line to length for routing to the fuel pump on the rear right side of the engine.

Install firesleeve over the fuel line completely covering the rubber line right up to the fittings at firewall and fuel pump.

Secure the ends of the firesleeve with a few wraps of safety wire.
Clamp the ends of the fuel line to the fitting and the fuel pump with the worm drive clamps provided.



Secure the fuel line to an engine mount member with cushioned clamps or other straps.

See photo below of the cabin side of the firewall fuel fitting.

